


EXPLODED VIEW
MODEL: B14B



B14B SERVICE PARTS LIST

Updated December 30, 2008

No.	Part name	Part No.	Q'ty	No.	Part name	Part No.	Q'ty
1	No-Spill Kit (CN3-PF)	24-012	1	18	PTC	05-021-003	1
1-1	Air Filter Ass'y	24-101-008	1	19	OLP	05-020-003	1
1-2	No-Spill Kit	03-152	1	20	PTC Cover	05-022-001	1
2	Top Cover	03-151	1	21	Compressor	05-003B-029	1
3	Bottle Guide Packing	09-037	1	22	Base-Compressor	02-076-001	1
4	Side Insulation-Cold Water Tank	08-022	1	23	Bottom Base	03-153	1
5	Cold Water Baffle	03-107-001	1	24	Front Panel-Lower Seat Rubber	09-055	2
6	Cold Water Tank Fitting Nut	03-067	1	25	Front Panel-Upper	03-149	1
7	Cold Water Tank Ass'y	-	1	26	Faucet Ass'y	23-015A-010D 23-016A-010D	2
7-1	Cold Water Tank	02-003-010	1	27	Silicone Washer-Faucet	09-003	2
7-2	Evaporator	10-002	1	28	Front Panel-Lower	03-150	1
7-3	Cable Tie	17-003	1	29	Grid-Drip Tray	03-156	1
7-4	Insulation-Suction Tube	08-005-004	1	30	Drip Tray	03-155	1
7-5	Heat Shrinkable Tube	05-005	1	31	Lower-Name Plate	03-158B	1
8	Silicone-Outlet Pipe	09-001	1	32	Cord Bushing	07-006-003	1
9	Plug-Patition Tube	09-039	2	33	Power Supply Cord	07-052-005	1
10	Patition Tube	03-113	1	34	Capillary Tube	10-003-001	1
11	Lower Insulation-Cold Water Tank	08-023-001	1	35	Drier	05-002-001	1
12	Base-Cold Water Tank	02-075	1	36	Wire Condenser	05-008-009	1
13	Control Panel	02-073	1	37	Cord Hook	03-159	2
14	Cold Water Thermostat	07-001	1	38	Side Panel	02-074	2
15	Wire Ass'y	07-116	1	39	Protector-Side Panel	03-020	4
16	Split Pin	12-009-001	4	40	Rear Panel	03-154	1
17	Seat Rubber-Compressor	09-048-002	4	41	Spare Fuse	07-003-019	1