


EXPLODED VIEW  
MODEL:D14B



**D14B SERVICE PARTS LIST**

Updated December 30, 2008

NO	PART NAME	PART NO	Q'TY	NO	PART NAME	PART NO	Q'TY
1	Top Cover(POU)	03-169	1	15	Split Pin	12-009-001	1
2	Float Valve Ass'y	25-004	1	16	Seat Rubber-Compressor	09-048-002	4
2-1	Float Valve Reset Packing	09-052	1	17	OLP	05-020-003	1
2-2	Air Filter	08-021	1	18	PTC	05-021-003	1
2-3	Elbow Union	10-009-008	1	19	PTC Cover	05-022-001	1
2-4	Float Valve Cover	03-147	1	20	Compressor	05-003B-029	1
2-5	Packing	09-037-001	1	21	Base-Compressor	02-076-001	1
2-6	Float Valve Body	03-144	1	22	Bottom Base	03-153	1
2-7	Float Valve	03-145	1	23	Front Panel-Lower Seat Rubber	09-055	2
3	Side Insulation-Cold Water Tank	08-022	1	24	Front Panel-Upper	03-149	1
4	Cold Water Baffle	03-107-001	1	25	Faucet Ass'y	23-015A-010D 23-016A-010D	2
5	Cold Water Tank Fitting Nut	03-067	1	26	Silicon Washer-Faucet	09-003	2
6	Cold Water Tank Ass'y	-	1	27	Front Panel-Lower	03-150	1
6-1	Cold Water Tank	02-003-010	1	28	Grid-Drip Tray	03-156	1
6-2	Evaporator	10-002	1	29	Drip Tray	03-155	1
6-3	Insulation-Suction Pipe	08-005-004	1	30	Lower-Name Plate	03-158B	1
6-4	Cable Tie	17-003	1	31	Cord Bushing	07-006-003	1
6-5	Heat Shrinkable Tube	05-005	1	32	Power Cord	07-052-005	1
7	Silicon-Outlet Pipe	09-001	1	33	Capillary Tube	10-002	1
8	Plug-Patition Tube	09-039	2	34	Drier	05-002-001	1
9	Patition Tube	03-113	1	35	Wire Condenser	05-008-009	1
10	Lower Insulation-Cold Water Tank	08-023-001	1	36	Cord Hook	03-159	2
11	Base-Cold Water Tank	02-075	1	37	Side Panel	02-074	2
12	Control Panel	02-073	1	38	Protector-Side Panel	03-020	4
13	Cold Water Thermostat	07-001	1	39	Rear Panel	03-154	1
14	Wire Ass'y	07-116	1	40	Spare Fuse	07-003-019	1